

HAIRSTYLING TRIPLE BARREL WAVER IRON OSOM PROFESSIONAL

OSOM8703

USER MANUAL


ORIGINAL INSTRUCTIONS OF USAGE

Thank you for purchasing one of our products. Please carefully read all the instructions before using and keep them for further usage. This device should only be used according to the intended purpose. Always keep away from water.

Functionality:

- The device will help you to form stylish and attractive waves.
- 2 ceramic heating plates will quickly heat up to 220° C.
- Dual voltage for convenient use in any country.
- Automatic shutdown after 1 hour of non usage.
- Swivel 360° angle cord.
- Adjustable temperature of 5 settings for all hair types: 140 – 220° C.

Safety instructions:

1. Before using the device check if the voltage indicated on appliance corresponds to your local voltage.
2. Do not use the appliance with wet hands, being wet or barefoot.
3. Always turn off and unplug the appliance immediately after use.
4. Do not leave the device unattended.
5. Keep the device away from water.
6. Do not use the appliance while bathing or showering.
-  7. Never place or store the appliance where it can fall or be pulled into tub or sink or other containers or basin filled with water. Do not wash the appliance and immerse it into water or other liquids.
8. If for any reason the appliance makes contact with water, unplug the appliance immediately and do not reach into water.
9. Never use the appliance if the cord or plug has been damaged, if it is not working properly or if has made contact with water. Contact Technical Maintenance Centre.
10. Keep away the appliance and appliance cord away from hot surfaces, flame and do not put it on hot surfaces. Never wrap the cord around the appliance, as this may result in damage to the cord-appliance connection and could cause the cord to fray and break. Do not pull the plug from electrical outlet with cord.
11. Never use the appliance if you feel drowsy, dizzy or unwell.
12. Do not use the appliance outdoors or operate where aerosol (spray) products are being used.
13. **CAUTION:** This appliance is hot when in use. To avoid burn hazard, do not let eyes and bare skin touch heated surface. Do not put heated appliance on soft, made of fabric flammable surfaces.
14. The appliance is not designed to be used by persons, including children, with a diminished physical, sensory or mental capacity or lack of experience and / or lack of knowledge unless supervised by a person who has provided the proper instruction or training in how to use the appliance.

15. It is forbidden for children to play with the appliance. Do not allow the children to clean and maintain the appliance without supervision. Close supervision is necessary when this appliance is being used near the children.

Usage:

1. Plug the appliance into electrical outlet with suitable voltage.
2. Click the „On/Off” button, on the external part of the device, that it could start heating.
3. Set the temperature from 140-220° C, while pressing the button. After changing the temperature, indicator light will change.
4. Divide hair into 4 sections.
5. Style each section of the hair separately, while pressing them with the device and gently sliding to the ends. After that, loosen the pressure and let hair to slip out from the heating plates.
ADVICE: keep 5-8 seconds for fine hair and 10-15 seconds for normal and thick hair.
6. Let hair to cool down. Do not brush the hair in order not to damage the waves.
7. After usage of the device, always turn off the device while pressing „On/Off” button for a longer time and plug the device from electrical outlet. Let the device to cool down before storing.

Temperature settings	Hair types
140-160°C	Fine hair
160-180°C	Normal hair
180-220°C	Thick, rough hair

Care and maintenance:

- Unplug the appliance before cleaning and let it fully cool down.
- Do not use for cleaning any abrasive, acidic cleaners, bleaches, products containing alcohol and flammable chemicals.
- Clean the appliance only with dry, soft cloth.
- Never wrap the cord around the appliance and pull the cord.

Technical specifications:

- Voltage: 100-240 V
- Frequency: 50-60 Hz
- Power: 88 W
- Adjustable temperature: 140 – 220° C
- Cord’s length: 2,5 m

Waste of Electrical Equipment



Pursuant to 2012/19 EU directive, regarding waste of electrical and electronic equipment, it is forbidden to throw non usable electrical equipment together with household waste. Separating this product for subsequent recycling will help to prevent potential environmental and health risks and allow the materials which make up the appliance to be re-used and recycled.

UAB „Krinona“ Authorised Technical Maintenance (Repair) Centre
Raudondvario pl. 162, Kaunas
Tel.: (8-37) 215104, mob.tel. 8 640 33213, 8 655 94090
More information: www.krinona.lt
Importer: UAB „Krinona“, A. Strazdo st. 70, Kaunas. Tel. 8 649 40000

GARANTINIO APTARNAVIMO SUTARTIS

Prekės pavadinimas

Modelis

Serijos numeris (nurodyti, jei yra)

Pardavimo data: 20 mėn. d. Kaina

Garantinis laikotarpis mėnesiais: 12 24 36 48

Pardavėjas

Garantinis laikotarpis profesionaliai technikai - 12 mėn.

Pardavėjo parašas

GARANTIJOS SĄLYGOS

- Pristatant prekę į „Krinona“ serviso centrą, ji privalo būti išvalyta. Transportuojant kurjerių pagalba prekė turi būti siunčiama saugų transportavimą užtikrinančioje pakuotėje.
- Prieš pradėdami naudotis preke, primygtinai rekomenduojame perskaityti prekės Vartotojo vadovą ir juo vadovautis. Vartotojo vadovą galite rasti www.krinona.lt. Papildomos informacijos apie prekės naudojimą ieškokite [Youtube.com](https://www.youtube.com) nurodymais prekės modelį ir/arba pavadinimą.
- Gedimo atveju, pirkėjas gali kreiptis į „Krinona“ servisą arba prekės pardavėją.
- Garantinis terminas pradėdamas skaičiuoti nuo prekės įsigijimo dienos ir baigiasi LR įstatymų numatyta tvarka, jeigu prekės įsigijimo sutartis nenumato kitaip.
- Pirkėjas, pristatydamas prekę garantiniam aptarnavimui, privalo pateikti prekės įsigijimo faktą patvirtinantį dokumentą.
- Prekės skirtos TIK BUITINIAM NAUDOJIMUI, pardavėjas pasilieka teisę netaikyti garantinių įsipareigojimų jei buitiniam naudojimui skirta prekė buvo naudojama komerciniams tikslais t.y. naudojama pajamoms gauti ar perleista tretiesiems asmenims nuomos pagrindu.
- Suremontavus arba pakeitus sugedusią prekę, garantijos terminas ir sąlygos galioja likusį garantijos laiką, bet ne trumpiau nei 3 mėn.
- Prekės spalvos / dangos pakitimai ar kosmetiniai paviršiaus pažeidimai, atsiradę eksploatacijos eigoje, nelaikomi gamykliniu defektu.
- Pardavėjas neįsipareigoja duoti pakaitinį įrenginį ar atlyginti menamą žalą dėl negalėjimo naudotis preke garantinio aptarnavimo atveju.
- Pardavėjas šias garantines sąlygas užtikrina tik Lietuvos teritorijoje.
- Nesant techninėms galimybėms sugedusią prekę pataisyti, prekė keičiama nauja ne prastesnių techninių parametrų preke arba už ją grąžinami pinigai (pinigų grąžinimo atveju privaloma grąžinti pilną komplektą išskyrus pakuotę).
- Fizinėms asmenims įsigytais prekėmis taikomas 24 mėn., o juridinių asmenų 12 mėn. garantinio aptarnavimo terminas, (Pardavėjas pasilieka teisę nustatyti ilgesnį garantinį terminą), bet eksploatacinėms dalims, kurių techninės charakteristikos tiesiogiai priklauso nuo eksploatacijos intensyvumo ir kinta eksploatacijos eigoje, priklausomai nuo naudojimo intensyvumo ir įpročių garantija gali būti apribota*

GARANTIJA NĖRA TAIKOMA:

- Mechanškai pažeistai ar ne UAB „Krinona“ įgaliotame servise ardytai / sąmoningai sugadintai prekei.
- Prekei, kuri buvo naudojama ne pagal paskirtį, įskaitant buitinių prietaisų naudojimą komerciniams tikslams.
- Prekei, kurios gedimas atsirado dėl pirkėjo kaltės, įskaitant netinkamo (kieto) vandens naudojimo sukeltas pasekmes (užkalkėjimas), į įrenginio vidų patekusį skystį, statybines dulkes, svetimkūnius, vabzdžius ir kt.
- Prekei, kurios gedimas atsirado dėl aplinkos veiksnių (lietaus, gaisro, potvynio, vėjo ar sniego, viršįtampių el. tinkle).
- Programinei įrangai, parduodamai kartu su preke.
- Filtrams, plastmasiniams indams, antgaliams, žarnoms, peiliukams, ašelėms, sieteliams, tinkleliams, dirželiams, gofoms, nuotolinio valdymo pultams, prekių priedams ir dalims bei mazgams, kurių eksploataavimo laikas yra ribotas ir tiesiogiai priklauso nuo eksploatacijos intensyvumo bei įpročių.

*Baterijoms / akumuliatoriams taikomas 6 mėn. garantinis terminas, po jo eksploatacijos eigoje baterijos / akumuliatoriaus techninės charakteristikos ir savybės gali natūraliai prastėti, bet tai nebus traktuojama kaip gamyklinis defektas. Tai tiesiog natūrali eksploatacijos pasekmė.

GARANTINIS REMONTAS ATLIEKAMAS
UAB „Krinona“, Raudondvario pl. 162, LT47174, Kaunas.
Tel. 8 640 33213 / 8 655 94090
el. paštas - servisas@krinona.lt